

How To Keep Your Drip System Components From Breaking During A Freeze

When the weather is going to be below 32 degrees.

Step 1: Push the manual button on the drip timer.

Step 2: Turn the top valve to the off position on the wall in the garage to the hose bibs.

This will drain the water out of the system and it won't freeze and break your drip system components.

Once freeze event is complete

Step 3: Turn the top valve to open(on) position on the wall in the garage to the hose bibs.